

SPRINT 4

| | |
|----------------------|---|
| TEAM ID | PNT2022TMID40888 |
| PROJECT TITLE | Personal Assistance for seniors who are self-Reliant |

PROGRAM:

```
#include <LiquidCrystal.h>
#include <stdio.h>
#define mSTATE_1 1
#define mSTATE_2 2
#define mSTATE_3 3
#define mSTATE_4 4
#define mSTATE_5 5
#define mSTATE_6 6
#define mSTATE_7 7
#define mSTATE_8 8
#define mSTATE_9 9
#define ALARM_SWITCH_PIN 2
#define BUZZER_PIN A3
typedef struct
{
    bool ALARM_SWITCH;
    bool RTC_ALARM;
    unsigned long RTC_TIME;
    unsigned long RTC_DATE;
    char RTC_TIME_C[20];
    char RTC_DATE_C[20];
}STATE_VAR;
typedef struct
{
    bool alarm_enable;
    bool alarm_flag;
    int alarm_min;
    int alarm_hour;
    int tick;
    int mls;
    int sec;
    int min;
    int hour;
    int month;
    int day;
    int year;
}RTC_DATA;
void get_input();
void fsm1(STATE_VAR *FSM_VAR);
```

```

void printLCDEMsgFromStart(LiquidCrystal *lcd, const char* Message, unsigned int row, bool
lcdclear);
void Buzzer(bool ON, int Buzzer_PIN);
float readTemperature(int TempSensor_PIN);
void RTC(RTC_DATA* rtc);
void RTC_Init(RTC_DATA* rtc, int tick);
void RTC_SetTime(RTC_DATA* rtc, int hour, int min, int sec);
void RTC_SetDate(RTC_DATA* rtc, int year, int month, int day);
void RTC_SetAlarm(RTC_DATA* rtc, int hour, int min);
void RTC_EnableAlarm(RTC_DATA* rtc);
void RTC_DisableAlarm(RTC_DATA* rtc);
bool RTC_GetAlarmStatus(RTC_DATA* rtc);
long RTC_GetTimeHHMMSS(RTC_DATA* rtc);
long RTC_GetDateYYYYMMDD(RTC_DATA* rtc);
long RTC_GetDateMMDD(RTC_DATA* rtc);
STATE_VAR FSM1_VAR;
RTC_DATA rtc;
LiquidCrystal lcd(A4, A5, 13, 12, 11, 10);
void setup()
{
  Serial.begin(9600);
  pinMode(ALARM_SWITCH_PIN, INPUT);
  lcd.begin(16, 2);
  lcd.setCursor(0, 0);
  RTC_Init(&rtc, 100);
  RTC_SetTime(&rtc, 11, 00, 0);
  RTC_SetDate(&rtc, 2020, 7, 7);
  RTC_SetAlarm(&rtc, 11, 36);
  RTC_EnableAlarm(&rtc);
}
void get_input()
{
  String Date;
  String Time;
  FSM1_VAR.ALARM_SWITCH = digitalRead(ALARM_SWITCH_PIN);
  FSM1_VAR.RTC_ALARM = RTC_GetAlarmStatus(&rtc);
  FSM1_VAR.RTC_TIME = RTC_GetTimeHHMMSS(&rtc);
  FSM1_VAR.RTC_DATE = RTC_GetDateYYYYMMDD(&rtc);
  if(FSM1_VAR.ALARM_SWITCH == 0)
  FSM1_VAR.ALARM_SWITCH = true;
  else
  FSM1_VAR.ALARM_SWITCH = false;
  if(rtc.min < 10 && rtc.sec < 10)
  Time = String(rtc.hour) + ':' + '0' + String(rtc.min) + ':' + '0' + String(rtc.sec);
  else if (rtc.min >= 10 && rtc.sec < 10)
  Time = String(rtc.hour) + ':' + String(rtc.min) + ':' + '0' + String(rtc.sec);
  else if(rtc.min < 10 && rtc.sec >= 10)
  Time = String(rtc.hour) + ':' + '0' + String(rtc.min) + ':' + String(rtc.sec);
  else
  Time = String(rtc.hour) + ':' + String(rtc.min) + ':' + String(rtc.sec);
  Date = String(rtc.day) + '/' + String(rtc.month) + '/' + String(rtc.year);
  strcpy(FSM1_VAR.RTC_TIME_C, Time.c_str());
}

```

```

strcpy(FSM1_VAR.RTC_DATE_C, Date.c_str());

}
void loop()
{
RTC(&rtc);
get_input();
fsm1(&FSM1_VAR);
delay(100);
}
void fsm1(STATE_VAR *FSM_VAR)
{
static int MACHINE_STATE;
static bool BUZZER;
bool ALARM_SWITCH = FSM_VAR->ALARM_SWITCH;
bool RTC_ALARM = FSM_VAR->RTC_ALARM;
long RTC_TIME = (FSM_VAR->RTC_TIME / 100);
long RTC_DATE = FSM_VAR->RTC_DATE;
Serial.print("DATE (YYYYMMDD): ");
Serial.print(RTC_DATE);
Serial.print(" TIME (HHMM): ");
Serial.println(RTC_TIME);
switch(MACHINE_STATE)
{
case mSTATE_1:
Serial.println("mSTATE_1");
if(!RTC_ALARM){
printLCDEMsgFromStart(&lcd, FSM_VAR->RTC_DATE_C, 1, false);
printLCDEMsgFromStart(&lcd, FSM_VAR->RTC_TIME_C, 2, false);
MACHINE_STATE = mSTATE_1 ;
}
else if(RTC_ALARM){
printLCDEMsgFromStart(&lcd, "WARNING", 1, true);
printLCDEMsgFromStart(&lcd, "ALARM!!", 2, false); BUZZER = true; MACHINE_STATE =
mSTATE_2;
}
else
{}
break;
case mSTATE_2:
Serial.println("mSTATE_2");
if(!ALARM_SWITCH){
MACHINE_STATE = mSTATE_2;
}
else if(ALARM_SWITCH){
RTC_DisableAlarm(&rtc); BUZZER = false; printLCDEMsgFromStart(&lcd, FSM_VAR-
>RTC_DATE_C, 1, true);
printLCDEMsgFromStart(&lcd, FSM_VAR->RTC_TIME_C, 2, false); MACHINE_STATE =
mSTATE_1;
}
else
{}
}

```

```

break;
default:
BUZZER = false;
MACHINE_STATE = mSTATE_1;
}
Buzzer(BUZZER, BUZZER_PIN);
}
void printLCDEmsgFromStart(LiquidCrystal *lcd, const char* Message, unsigned int row, bool
lcdclear)
{
if(lcdclear)
{
lcd->clear();
}
switch(row)
{
case 1:
lcd->setCursor(0, 0);
break;
case 2:
lcd->setCursor(0, 1);
break;
default:
lcd->setCursor(0, 0);
}
if(Message != NULL)
{
lcd->print(Message);
}
}
void Buzzer(bool ON, int Buzzer_PIN)
{
static bool ON_STATE;
if (ON_STATE == false && ON == true)
{
ON_STATE = true;
tone(Buzzer_PIN, 2000);
}
else if (ON == false)
{
ON_STATE = false;
noTone(Buzzer_PIN);
}
else
{}
}
float readTemperature(int TempSensor_PIN)
{
float Temperature;
Temperature = (float) analogRead(TempSensor_PIN);
Temperature = (Temperature * 5.0) / 1024.0;
Temperature = Temperature - 0.5;

```

```

Temperature = Temperature * 100;

return Temperature;
}
void RTC(RTC_DATA* rtc)
{
static bool ALARM;
rtc->mls = rtc->mls + rtc->tick;
if(rtc->mls == 1000)
{
rtc->mls = 0;
rtc->sec++;
}
if(rtc->sec >= 60)
{
rtc->sec = 0;
rtc->min++;
}
if(rtc->min >= 60)
{
rtc->sec = 0;
rtc->min = 0;
rtc->hour++;
}
if(rtc->min < 0)
{
rtc->sec = 0;
rtc->min = 59;
rtc->hour--;
}
if(rtc->hour >= 24)
{
rtc->sec = 0;
rtc->min = 0;
rtc->hour = 0;
rtc->day++;
}
if(rtc->month != 2 && (rtc->month % 2) == 1)
{
if(rtc->day == 32)
{
rtc->day = 1;
rtc->month++;
}
if(rtc->day < 1)
{
rtc->day = 30;
rtc->month--;
}
}
if(rtc->month != 2 && (rtc->month % 2) == 0)
{
if(rtc->day == 31)

```

```

{rtc->day = 1;
rtc->month++;
}
if(rtc->day < 1)
{
rtc->day = 31;
rtc->month--;
}
}
if(rtc->month == 2)
{
if(rtc->day == 29)
{
rtc->day = 1;
rtc->month++;
}
}
if(rtc->month == 3)
{
if(rtc->day < 1)
{
rtc->day = 28;
rtc->month--;
}
}
if(rtc->hour < 0)
{
rtc->hour = 23;
}
if(rtc->month > 12)
{
rtc->month = 1;
rtc->day = 1;
rtc->year++;
}
if(rtc->alarm_enable == 1 && rtc->alarm_flag == 0)
{
if(rtc->min == rtc->alarm_min && rtc->hour == rtc->alarm_hour)
{
rtc->alarm_flag = 1;
}
}
}
void RTC_Init(RTC_DATA* rtc, int tick)
{
rtc->tick = tick;
rtc->alarm_flag = 0;
rtc->alarm_enable = 0;
}
void RTC_SetTime(RTC_DATA* rtc, int hour, int min, int sec)
{
rtc->sec = sec;



```



```

rtc->min = min;
rtc->hour = hour;
}
void RTC_SetDate(RTC_DATA* rtc, int year, int month, int day)
{
rtc->day = day;
rtc->month = month;
rtc->year = year;
}
void RTC_SetAlarm(RTC_DATA* rtc, int hour, int min)
{
rtc->alarm_min = min;
rtc->alarm_hour = hour;
}
void RTC_EnableAlarm(RTC_DATA* rtc)
{
rtc->alarm_enable = 1;
rtc->alarm_flag = 0;
}
void RTC_DisableAlarm(RTC_DATA* rtc)
{
rtc->alarm_enable = 0;
rtc->alarm_flag = 0;
}
long RTC_GetTimeHHMMSS(RTC_DATA* rtc)
{
long time;
time = ((long)(rtc->hour) * 10000) + ((long)(rtc->min) * 100) + (long)(rtc->sec);
return time;
}
bool RTC_GetAlarmStatus(RTC_DATA* rtc)
{
return rtc->alarm_flag;
}
long RTC_GetDateYYYYMMDD(RTC_DATA* rtc)
{
long date;
date = ((long)(rtc->year) * 10000) + ((long)(rtc->month) * 100) + (long)(rtc->day);
return date;
}
long RTC_GetDateMMDD(RTC_DATA* rtc)
{
long date;
date = ((long)(rtc->month) * 100) + (long)(rtc->day);
return date;
}

```

CIRCUIT DIAGRAM:





CIRCUIT LINK:

https://www.tinkercad.com/things/11y22QRptwF-exquisite-sango-amberis/editel?sharecode=WMX2HfQyEbrpuqFJMKTRB9k1A-CYCyxY3TT1jHh_HTw

Using Wowki:

```
#include <WiFi.h>//library for wifi
#include <PubSubClient.h>//library for MQTT
#include <LiquidCrystal_I2C.h>
#include "DHT.h"// Library for dht11
#define DHTPIN 15      // what pin we're connected to
#define DHTTYPE DHT11  // define type of sensor DHT 11
#define LED 2
DHT dht (DHTPIN, DHTTYPE);// creating the instance by passing pin and typr of
dht connected
void callback(char* subscribetopic, byte* payload, unsigned int
payloadLength);

//-----credentials of IBM Accounts-----

#define ORG "64yf7x"//IBM ORGANITION ID
#define DEVICE_TYPE "b11m3edevicetype"//Device type mentioned in ibm watson
IOT Platform
#define DEVICE_ID "b11m3edeviceid"//Device ID mentioned in ibm watson IOT
Platform
#define TOKEN "-&EMtr7l-v-Gz2G))e"      //Token
String data3="";
int buzz= 13;

//----- Customise the above values -----
char server[] = ORG ".messaging.internetofthings.ibmcloud.com";// Server Name
char publishTopic[] = "iot-2/evt/Data/fmt/json";// topic name and type of
event perform and format in which data to be send
char subscribetopic[] = "iot-2/cmd/command/fmt/String";// cmd REPRESENT
command type AND COMMAND IS TEST OF FORMAT STRING
char authMethod[] = "use-token-auth";// authentication method
char token[] = TOKEN;
char clientId[] = "d:" ORG ":" DEVICE_TYPE ":" DEVICE_ID;//client id
LiquidCrystal_I2C lcd(0x27,32,2);

//-----
WiFiClient wifiClient; // creating the instance for wificlient
PubSubClient client(server, 1883, callback ,wifiClient); //calling the
predefined client id by passing parameter like server id,portand
wificredential

void setup()// configureing the ESP32
{

  Serial.begin(115200);
  dht.begin();
```

```

    pinMode(buzz, OUTPUT);
    pinMode(LED,OUTPUT);
    delay(10);
    Serial.println();
    wificonnect();
    mqttconnect();
}

void loop()// Recursive Function
{
    if (!client.loop()) {
        mqttconnect();
    }
}

/*.....retrieving to
Cloud.....*/

void PublishData(float temp, float humid) {
    mqttconnect();//function call for connecting to ibm
}

void mqttconnect() {
    if (!client.connected()) {
        Serial.print("Reconnecting client to ");
        Serial.println(server);
        while (!client.connect(clientId, authMethod, token)) {
            Serial.print(".");
            delay(500);
        }

        initManagedDevice();
        Serial.println();
    }
}

void wificonnect() //function defination for wificonnect
{
    Serial.println();
    Serial.print("Connecting to ");

    WiFi.begin("Wokwi-GUEST", "", 6);//passing the wifi credentials to establish
the connection
    while (WiFi.status() != WL_CONNECTED) {
        delay(500);
        Serial.print(".");
    }
}

```

```

    Serial.println("");
    Serial.println("WiFi connected");
    Serial.println("IP address: ");
    Serial.println(WiFi.localIP());
}

void initManagedDevice() {
    if (client.subscribe(subscribetopic)) {
        Serial.println((subscribetopic));
        Serial.println("subscribe to cmd OK");
    } else {
        Serial.println("subscribe to cmd FAILED");
    }
}

void callback(char* subscribetopic, byte* payload, unsigned int payloadLength)
{
    Serial.print("callback invoked for topic: ");
    Serial.println(subscribetopic);
    for (int i = 13; i < payloadLength-2; i++) {
        //Serial.print((char)payload[i]);
        data3 += (char)payload[i];
    }

    Serial.println("Medicine Name: "+ data3);
    if(data3 != "")
    {
        lcd.init();

        lcd.print(data3);
        digitalWrite(LED,HIGH);
        tone(buzz, 100, 1000);
        delay(2000);
        digitalWrite(LED,LOW);
        noTone(buzz);
        delay(1000);

    }

    else
    {
        digitalWrite(LED,LOW);

    }
    data3="";
}

```

WOKWI SAVE SHARE Medicine Remainder Docs

PNT2022TMD50622.ino diagram.json libraries.txt Library Manager

```

1 #include <WiFi.h> //library for wifi
2 #include <PubSubClient.h> //library for MQTT
3 #include <LiquidCrystal_I2C.h>
4 #include "DHT.h" // Library for dht11
5 #define DHTPIN 15 // what pin we're connected to
6 #define DHTTYPE DHT11 // define type of sensor DHT 11
7 #define LED 2
8 DHT dht (DHTPIN, DHTTYPE); // creating the instance by passing pin and type of dht
9 void callback(char* subscribetopic, byte* payload, unsigned int payloadLength);
10
11
12 //-----credentials of IBM Accounts-----
13
14 #define ORG "64y7x" //IBM ORGANITION ID
15 #define DEVICE_TYPE "b1m3edevicetype" //Device type mentioned in ibm watson IOT
16 #define DEVICE_ID "b1m3edeviceid" //Device ID mentioned in ibm watson IOT Platfo
17 #define TOKEN "&EMtr71-v-Gz2G)e" //Token
18 String data3="";
19 int buzz= 13;
20
21 //----- Customise the above values -----
22 char server[] = ORG ".messaging.internetofthings.ibmcloud.com"; // Server Name
23 char publishTopic[] = "iot-2/evt/data/fmt/json"; // topic name and type of event
24 char subscribetopic[] = "iot-2/cmd/command/fmt/String"; // cmd REPRESENT command
25 char authMethod[] = "use-token-auth"; // authentication method
26 char token[] = TOKEN;
27 char clientId[] = "d:" ORG ":" DEVICE_TYPE ":" DEVICE_ID; //client id
28 LiquidCrystal_I2C lcd(0x27,16,2);
29
30 //-----
31 WiFiClient wifiClient; // creating the instance for wifiClient
32 PubSubClient client(server, 1883, callback, wifiClient); //calling the predefined
33
34 void setup() // configuring the ESP32
35 {
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100


```

Simulation

Medicine Name: acetaminophen
callback invoked for topic: iot-2/cmd/command/fmt/String
Medicine Name: acetaminophen
callback invoked for topic: iot-2/cmd/command/fmt/String
Medicine Name: acetaminophen
callback invoked for topic: iot-2/cmd/command/fmt/String
Medicine Name: acetaminophen

- software (create device in the iot watson platform, workflow for iot scenarios using local node red).

create device in the iot watson platform:



IBM Watson IoT Platform

611819104022@smartinternz.com
ID: friec

Browse Action Device Types Interfaces

Search by Device ID

Device Simulator

| Device ID | Status | Device Type | Class ID | Date Added |
|-----------|--------------|-------------|----------|----------------------|
| 09 | Disconnected | IoT | Device | Nov 20, 2022 4:30 PM |

Identity Device Information Recent Events State Logs

Device ID: 09
Device Type: IoT
Date Added: Nov 20, 2022 4:30 PM
Added By: 611819104022@smartinternz.com
Connection Status: Disconnected

Items per page 50 | 1-1 of 1 item

1 Simulation running

IBM Watson IoT Platform

611819104022@smartinternz.com
ID: friec

Browse Action Device Types Interfaces

All Devices Diagnose

This table shows a summary of all devices that have been added. It can be filtered by criteria. To get started, you can add devices by using the Add Device button, or by using the Add Device button.

Search by Device ID

| Device ID | Status | Device Type |
|-----------|--------------|-------------|
| 09 | Disconnected | IoT |

Items per page 50 | 1-1 of 1 item

Device Type: IoT

Events 1

New event type

Event type name: medicinedata

Schedule: 1 Every Minute

Payload

Specify the event payload in the editor window or by uploading a CSV file.

```
0 {  
1   "Enter the Medicine": "Amoxicillin",  
2   "time": "11:01",  
3   "date": "7/7/20"  
4 }  
5 }
```

IBM Watson IoT Platform

Device Type: IoT

Events 1

Event type name: medicinedata

Schedule: 1 Every Minute

Payload: {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"}

| Event | Value |
|--------------|--|
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} |

Items per page 50 | 1-1 of 1 item

IBM Watson IoT Platform

Device Type: IoT

Events 1

Event type name: medicinedata

Schedule: 1 Every Minute

Payload: {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"}

| Event | Value | Format | Last Received |
|--------------|--|--------|-------------------|
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} | json | a few seconds ago |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} | json | a few seconds ago |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} | json | a few seconds ago |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} | json | a few seconds ago |
| medicinedata | {"Enter the Medicine": "Amoxicillin", "time": "11:01", "date": "7/7/20"} | json | a few seconds ago |

Items per page 50 | 1-1 of 1 item

1 Simulation running

The screenshot shows the IBM Watson IoT Platform dashboard. The user is logged in as 'frieec' with ID '611819104022@smartinternz.com'. The dashboard displays a list of devices, and one device is selected, showing its 'State' tab. The state tab displays 'Showing Raw Data | No Interfaces Available' and a table of data points.

| Property | Value | Type | Event | Last Received |
|--------------------|-------------|--------|--------------|-------------------|
| Enter the Medicine | Amoxicillin | String | medicinedata | a few seconds ago |
| time | 11:01 | String | medicinedata | a few seconds ago |
| date | 7/7/20 | String | medicinedata | a few seconds ago |

At the bottom, it indicates '1 Simulation running'.

- Thus we created a device in that IoT platform, in this platform we store some medicine details, time and date.
- Then using the node-red, we connect IoT platform.

The screenshot shows the Node-RED on IBM Cloud landing page. The page has a red header with the text 'Node-RED' and 'Flow-based programming for the Internet of Things'. Below the header, there is a section with text about Node-RED and a button to go to the flow editor.


Node-RED is a programming tool for wiring together hardware devices, APIs and online services in new and interesting ways.

This instance is running as an IBM Cloud application, giving it access to the wide range of services available on the platform.

[Go to your Node-RED flow editor](#)

[Learn how to customise Node-RED](#)

More information about Node-RED, including documentation, can be



Node-RED interface showing the "Edit form node" dialog box. The dialog is titled "Edit form node" and includes a "Delete" button, "Cancel" button, and "Done" button.

Properties

- Group:** [TABLET] DETAILS
- Size:** auto
- Label:** optional label

Form elements

| Label | Name | Type | Required | UiRows | Remove |
|--------------------|----------|------|-------------------------------------|--------|--------|
| Enter the Medicine | medicine | Text | <input checked="" type="checkbox"/> | | |
| Date | Date | Text | <input checked="" type="checkbox"/> | | |
| Time | Time | Text | <input checked="" type="checkbox"/> | | |

☐ Enabled

TABLET

DETAILS

Enter the Medicine *

Date *

Time *

SUBMIT CANCEL

Node-red and Cloud database that store information:

Node-RED on IBM Cloud

Node-RED

Flow-based programming for the Internet of Things


Node-RED is a programming tool for wiring together hardware devices, APIs and online services in new and interesting ways.

This instance is running as an IBM Cloud application, giving it access to the wide range of services available on the platform.

More information about Node-RED, including documentation, can be

[Go to your Node-RED flow editor](#)

[Learn how to customise Node-RED](#)



Node-RED interface showing the "Edit form node" dialog for a form named "[TABLET] DETAILS".

Properties:

- Group: [TABLET] DETAILS
- Size: auto
- Label: optional label

Form elements:

| Label | Name | Type | Required | UiRows | Remove |
|--------------------|----------|------|-------------------------------------|--------|--------|
| Enter the Medicine | medicine | Text | <input checked="" type="checkbox"/> | | |
| Date | Date | Text | <input checked="" type="checkbox"/> | | |
| Time | Time | Text | <input checked="" type="checkbox"/> | | |

☐ Enabled

TABLET

DETAILS

Enter the Medicine *

Date *

Time *

SUBMIT CANCEL

TABLET

DETAILS

Enter the Medicine *

Amoxicillin.

Date *


7/7/20

Time *

11:01

SUBMIT CANCEL

- Here we created a form to store details of the medicine and what time we want to take medicine.



- The information are stored in database.

Resource list / **Node RED YRHOA 2022-11-19** Running [Visit App URL](#) [Add tags](#) [Details](#) [Actions...](#)

Getting started

Overview

Runtime

Connections

Logs

API Management

Autoscaling

Instances [Edit](#)

Health **100%**
1/1 instance(s) are running

Instances [-](#) [+](#)

MB memory per instance
0 2048 **256**

Runtime

Node.js

256
Total MB allocation

1.75 GB still available [?](#)

Free Used

Resource list / **node-red-yrhoa-2022--cloudant-1668880742648** Active [Add tags](#) [Details](#) [Actions...](#)

Manage [Launch Dashboard](#)

Service credentials

Plan

Connections

Overview Capacity Docs

Deployment details

CRN crn:v1:bluemix:public:cloudantnosqldb:au-syd:a/7c4e6245f4054550b72942e2e33d7c9a:17d31312-3e03-4b7e-9315-00345d68da6c::

Location Sydney

External endpoint <https://a5a69fd5-68c1-4cbc-a755-bbad3eb7f1a0-bluemix.cloudant.com>

External endpoint (preferred) <https://a5a69fd5-68c1-4cbc-a755-bbad3eb7f1a0-bluemix.cloudantnosqldb.appdomain.cloud>

[Migrate to IAM Only](#)

Database interface showing a list of documents in the 'database' collection. The interface includes a sidebar with navigation options (All Documents, Query, Permissions, Changes, Design Documents) and a main area displaying document details in a table view. The table columns are id, key, and value. The documents listed are:

| id | key | value |
|--------------------------------|--------------------------------|------------------------------------|
| 1a0df7c3bfa555c900c4464f9c0... | 1a0df7c3bfa555c900c4464f9c0... | { "rev": "1-ca666cb53e04f95e8fc... |
| 4a9a77563a47ffc10fa713cba1a... | 4a9a77563a47ffc10fa713cba1a... | { "rev": "1-ca666cb53e04f95e8fc... |
| 576214e1604914858be03f871a... | 576214e1604914858be03f871a... | { "rev": "1-ca666cb53e04f95e8fc... |
| 5dd2816e27807815e113fc0c05... | 5dd2816e27807815e113fc0c05... | { "rev": "1-ca666cb53e04f95e8fc... |
| 761b84dd40dfa2b62858bedc78... | 761b84dd40dfa2b62858bedc78... | { "rev": "1-ca666cb53e04f95e8fc... |
| 761b84dd40dfa2b62858bedc78... | 761b84dd40dfa2b62858bedc78... | { "rev": "1-ca666cb53e04f95e8fc... |
| bd671eb32bf444185746a72d5f... | bd671eb32bf444185746a72d5f... | { "rev": "1-ca666cb53e04f95e8fc... |



Database interface showing a list of documents in the 'medicinedata' collection. The interface includes a sidebar with navigation options (All Documents, Query, Permissions, Changes, Design Documents) and a main area displaying document details in a table view. The table columns are id, key, and value. The documents listed are:



| id | key | value |
|-------------------------------|-------------------------------|-----------------------------------|
| 57080a61861399b2b872f2cc54... | 57080a61861399b2b872f2cc54... | { "rev": "1-1920120a1be78b41a... |
| 9a48b4961b58adebb1ff35003e... | 9a48b4961b58adebb1ff35003e... | { "rev": "1-1f47da4e0c01089957... |


Database interface showing the details of a specific document in the 'medicinedata' collection. The document ID is 57080a61861399b2b872f2cc548847ac. The document content is displayed in a JSON format:

```
{
  "_id": "57080a61861399b2b872f2cc548847ac",
  "_rev": "1-1920120a1be78b41aeeeb276a8198ea1",
  "payload": {
    "Name": "Amoxicillin.",
    "Date": "7/7/20",
    "Time": "11:01"
  },
  "socketid": "is7A8f4V2h04SPpNAAAN"
}
```

Application for User:











USERNAME: 1234

PASSWORD:


SUBMIT

4G
11:00

Bluetooth
LTE1
0.00 KB/s

12

Get Alarm



Enter Alert Message

Enter a message

HourMin

Set Alarm

